



# Installation Quick Reference

SIP Compliant

011393\*, RAL 9002, Gray White, Standard 011394\*, RAL 9003, Signal White, Optional


\*Replaces the 011098 and 011099 numbers.



DHCP
10 10 10 10
10.10.10.10
admin
admin
255.0.0.0
10.0.0.1

a. Default if there is not a DHCP server present.


## Typical System Installation




## Getting Started

- Download the Operations Guide PDF file, from the Downloads tab at the following webpage: http://www.cyberdata.net/voip/011393/
- Create a plan for the locations of your SIP Speakers.
- WARNING: This product should be installed by a licensed electrician according to all local electrical and building codes.
- WARNING: To prevent injury, this apparatus must be securely attached to the floor/wall in accordance with the installation instructions.
- . WARNING: The PoE connector is intended for intra-building connections only and does not route to the outside plant.
- WARNING: This enclosure is not rated for any AC voltages!

### **Parts**




#### **Dimensions and Connections**




# **Connecting Power**






#### **Features**



## Mounting



#### **Tools Required for Installation:**

- (1) Sheetrock saw or
  - (1) Drywall cutter
- (1) #2 Phillips Screwdriver or
- (1) #2 Phillips Screwdriver Hex Bit

#### To mount a speaker:

- 1. Use the **TEMPLATE** on the back of this document to cut a hole in the wall or ceiling, and prepare holes for the screws.
- 2. Plug the Ethernet cable into the speaker assembly. The yellow light verifies the network connection.
- For drop ceiling mounting, position the IP SPEAKER ASSEMBLY in the ceiling so that its screw holes align with those you prepared.
- 4. For drywall mounting, place the three PLASTIC RIBBED ANCHORS in the holes you prepared, and position the IP SPEAKER ASSEMBLY over them, aligning the screw holes in the assembly with the anchors.
- For drop ceiling mounting\*, use the three 8-32 x 1 1/4" MOUNTING SCREWS, #8 NYLON THUMB NUTS, and #8 FENDER WASHERS to secure the speaker.

For drywall mounting, use the three #8 SHEET METAL SCREWS to secure the speaker.

\* For weak ceiling tile, CyberData offers a reinforcing mount (CyberData part number 010991).

# Contacting CyberData

## Corporate Headquarters

CyberData Corporation 3 Justin Court

Monterey, CA 93940, USA

Phone: 831-373-2601 Fax: 831-373-4193 http://www.cyberdata.net/

Quick Reference

Sales: (831) 373-2601 ext. 334 Support: 831-373-2601 ext. 333

Support Website: http://support.cyberdata.net/

RMA Department: (831) 373-2601 ext. 136 RMA Email: RMA@CyberData.net RMA Status: http://support.cyberdata.net/

b://www.cyberdata.net/

Warranty Information: http://support.cyberdata.net/